INT-TRF

MKN | Technical manual | Reading edition

Technical content from the original MKN document, reorganized for computer, mobile and printed reading. Diagrams and board markings are preserved. Check the model and revision before installation. Reference translation; consult the Portuguese original if in doubt.

interface three-phase INT-TRF connection diagram.

ELECTRICAL NETWORK three-phase

motor three-phase

Diagrams and visual reference

Original reference 1

